PARTS LIST

for

Whirlpool CORPORATION

27"ELECTRIC BUILT-IN DOUBLE OVEN

CONTINUOUS CLEAN LOWER OVEN
SELF-CLEAN UPPER OVEN

MODEL RB770PXT-2

Panoramic

FSP

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

FSP

Whirlpool CORPORATION
Benton Harbor, Michigan.

© 1990 WHIRLPOOL CORPORATION

8-90 Litho in U.S.A.

Part No. 816503

CONTROL PANEL AND LATCH PARTS

For Model: RB770PXT-2



2	877884	Axle, Latch
3	816384	Latch, Door
4	816289	Motor-Latch Assembly
	241428	Screw, 10-24 x 1/2 (3)
5	816454	Switch, Latch (2)
6	816331	Trim, Control Panel
7	816282	Plate, Motor Mounting
	241428	Screw, 10-24 x 1/2 (2)
8	816275	Housing, Control
	241428	Screw, 10-24 x 1/2 (2)
	308685	Screw, 10-24 x 1/2 (5)
9	816288	Rod, Latch
10	816335	Cover, Housing
11	241212	Terminal Block
	9426223	Screw, 10-16 x 1 (2)
12	877614	Housing, Latch
13	816276	Cover, Latch
15	816405	Escutcheon, Thermostat (Upper Oven)
16	816318	Thermostat, Oven (Lower)
24	816309	Bracket, Control
	241428	Screw, 10-24 x 1/2 (4)
25	816314	Thermostat, Oven (Upper)
	877919	Screw, 8-32 x 3/16 (2)
26	816445	Switch, Oven Light
27	816313	Switch, Oven Selector
	877919	Screw, 8-32 x 3/16 (2)
28	816316	Indicator Light (Clean)
	816315	Indicator Light (2) (Lock, Oven)
29	816310	Timer (Digital)
31	816311	Knob, Timer
32	816404	Panel, Glass (Control)
33	816322	Trim, Vent
	241428	Screw, 10-24 x 1/2 (4)
34	816334	Trim, Top
	487010	Screw, 6-32 x 1/2 (4)
36	816332	Bezel, Switch
37	816439	Button, Clock (4)
38	310834	Knob, Control (3)
39	868363	Bumper (6)
46	311068	Escutcheon, Selector Switch
	877919	Screw, 8-32 x 3/16
47	311067	Escutcheon, Thermostat (Lower Oven)
	877919	screw, 8-32 x 3/16

UPPER OVEN DOOR PARTS

For Model: RB770PXT-2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	816506	Frame, Oven Door
	816511	Screw, 8 x 10 (5)
2	816358	Handle, Oven Door
	816359	Screw, 10-24 x 2 (2)
3	816356	Glass, Outer
4	816441	Insulation, Oven Door
5	816508	Panel, Airwash
6	816513	Glass, Inner
7	816512	Spacer, Glass
8	816507	Liner, Oven Door
	816270	Screw, 10-24 x 5/8
9	816510	Baffle, Weldment
	816362	Screw, 10-24 x 2 3/4 (4)
10	816446	Seal, Oven Door
12	816363	Seal, Window
13	816385	Hinge Assy. (2)
	816270	Screw, 10-24 x 5/8 (4)
14	816415	Spacer, Door Handle (2)
15	816509	Collar, Glass
16	816440	Spacer, Handle (2)
17	816505	Spacer, Door (2)
19	877507	Strike
	816270	Screw, 10-24 x 5/8 (2)

UPPER OVEN PARTS

For Model: RB770PXT-2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	816273	Oven (27" Pyro)
3	877803	Receptacle, Light
4	816389	Bulb, Light
5	877804	Lens, Light
6	816291	Retainer, Lens
7	816379	Retainer, Door
8	816321	Switch, Oven Light
9	816295	Unit, Broil
	241428	Screw, 10-24 x 1/2 (2)
10	816297	Support, Broil Unit
	241428	Screw, 10-24 x 1/2 (2)
11	816293	Unit, Bake
	241428	Screw, 10-24 x 1/2 (2)
14	816442	Vent Tube
15	816277	Insulation Retainer, Top and Sides
16	816303	Casing, Top
18	816279	Casing, Back and Sides
	308685	Screw, 10-24 x 1/2 (14)
21	816287	Spring, Oven (2)
	241428	Screw, 10-24 x 1/2 (2)
23	816326	Duct, Oven Vent
	877919	Screw, 8-32 x 3/16
24	816328	Insulation
26	816386	Front Frame
	816270	Screw, 10-24 x 5/8 (6)
27	816319	Cover, Motor
	241428	Screw, 10-24 x 1/2 (2)
28	816387	Spacer, Oven
29	816388	Channel Assembly, Hinge (2)
34	816342	Rack, Oven Regular
35	816343	Rack, Oven Offset
36	816448	Grill, Broiler Pan
37	816437	Pan, Broiler
38	816329	Retainer

SPLICING WIRES-25 FT. LENGTH

242828	Wire, Black 12 Ga. 150oC
242820	Wire, Black 14 Ga. 150oC
242821	Wire, Blue 14 Ga. 150oC
242822	Wire, Brown 14 Ga. 150oC
242830	Wire, Brown 14 Ga. 200oC
242823	Wire, Green 14 Ga. 150oC
242824	Wire, Orange 14 Ga. 150oC
242829	Wire, Red 12 Ga. 150oC
242825	Wire, Red 14 Ga. 150oC
242831	Wire, Red 14 Ga. 200oC
242826	Wire, White 14 Ga. 150oC
242827	Wire, Yellow 14 Ga. 150oC
242832	Wire, Yellow 14 Ga. 200oC

INSULATION

261514	Insulation Fiberglass (1-1/2" x 24" x 120")
240132	Insulation Fiberglass (2-1/2" x 22" x 120")
241430	Foil, Aluminum Oven (18" x 25")

REFINISHING MATERIAL

261810	Touch-Up Oven (1 Oz.)
261582	Grease

LITERATURE PARTS

LIT816142	Guide, Use & Care
LIT816259	Instructions, Installation
LIT313358	Guide, Cooking
LIT816503	List, Repair Parts

LOWER OVEN PARTS

For Model: RB770PXT-2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1	816272	Oven (27")
3	877803	Receptacle, Light
4	816389	Bulb, Light
5	877804	Lens, Light
6	816291	Retainer, Lens
7	816300	Bracket, Vent Tube
8	816447	Vent Tube
9	816295	Unit, Broil
	241428	Screw, 10-24 x 1/2 (2)
10	816297	Support,
	241428	Screw, 10-24 x 1/2 (2) Broil Unit
11	816293	Unit, Bake
	241428	Screw, 10-24 x 1/2 (2)
12	816344	Trim, Base
	3149333	Screw, 10-16 x 1/2 (2)
13		Side Trim (Inner)
	816285	R.H.
	816286	L.H.
	308685	Screw, 10-24 x 1/2 (10)
14	816299	Vent Tube
15	816277	Insulation Retainer, Top and Sides
16	816301	Vent Tube
17	816278	Insulation Retainer, Bottom
	241428	Screw, 10-24 x 1/2 (4)
18	816280	Casing, Back and Sides
	308685	Screw, 10-24 x 1/2 (14)
19	816283	Casing, Bottom
20	816298	Duct, Oven
21	816287	Spring, Oven (2)
	241428	Screw, 10-24 x 1/2 (2)
22	816324	Side Trim, Outer (2)
	3149333	Screw, 10-16 x 1/2
23	816327	Duct, Oven Vent
	877919	Screw, 8-32 x 3/16
26	816407	Front Frame
	816270	Screw, 10-24 x 5/8 (6)
28	816284	Support, Height (2)
	308685	Screw, 10-24 x 1/2 (12)
29	816388	Channel Assembly, Hinge (2)
30	816341	Cover, Rear
	241428	Screw, 10-24 x 1/2 (8)
31	816333	End Cap, Top (2)
34	816342	Rack, Oven Regular
35	816328	Insulation
38	816329	Retainer

LOWER OVEN DOOR PARTS

For Model: RB770PXT-2



1	816354	Frame, Oven Door
	3149333	Screw, 10-16 x 1/2 (6)
2	816438	Handle, Oven Door
	816359	Screw, 10-24 x 2 (2)
3	816356	Glass, Outer
5	816351	Panel, Airwash
6	816377	Glass, Inner
8	816514	Liner, Oven Door
	816270	Screw, 10-24 x 5/8
10	816417	Seal, Oven Door
12	816376	Seal, Window
13	816406	Hinge Assy. (2)
	816270	Screw, 10-24 x 5/8 (4)
14	816415	Spacer, Door Handle
15	816367	Retainer, Glass
16	816440	Spacer, Handle (2)